



## Mounting more than 1 Sensor Switch on a single tile or faceplate.

If your tile or faceplate is relatively thin (up to 5mm thick) a spacing of 2 x the width of the Sensor Switch should be sufficient (fig 1); over that, because the sensing field fans out within the faceplate, you may have to position them further apart.(fig 2)

If it is not possible to position the Sensor Switch further apart, one possible solution is to lay an EARTH wire on the back surface of the tile, mid-way between the Sensor Pads. (fig 3)



If you need any further clarification, please call out helpdesk on 01548 511498

Sensorbility Ltd, West Prawle House, East Portlemouth, Salcombe. TQ8 8PW

[lights@sensor.co.uk](mailto:lights@sensor.co.uk)

[www.sensor.co.uk](http://www.sensor.co.uk)